

XL-2835

SYNTHETIC TRANSMISSION AND DRIVE AXLE LUBES

The **XL-2800** series of Synthetic Transmission and Drive Axle Lubes are formulated and approved to meet the exacting lubrication requirements for **Eaton™ Roadranger™** regular and extended warranties.

Subject to all terms and conditions of the **Eaton™ Roadranger™** “Warranty Statement” effective with any new vehicle sold on or after November 1, 1989, **Eaton™** will warrant specific models of transmissions and drive axles for a period of five years (optional seven years extended) or 1,200,000 km.

The **Eaton™ Roadranger™** warranty is expressly conditional upon the exclusive use of **Eaton™ Roadranger™** approved lubricants such as the **XL-2830** series of Synthetic Transmission and Drive Axle Lubes. Evidence of lubricant use including factory fill or replacement within 8,000 km of initial vehicle service, shall be required with any warranty claims.

The **XL-2800** series offer:

- All climate, year round performance
- Improved component protection
- Easier cold weather shifting
- Extended drain intervals
- Cooler running in hot weather
- Potential fuel economy

TYPICAL SPECIFICATIONS			
Product Code:	XL-2835	XL-2836	XL-2837
Application:	Drive Axle	Transmission	Drive Axle
SAE Grade (J306-B)	80W140	50	75W90
AGMA Grade (ASTM D-2422)	5-6 EP	-	4 EP
Viscosity (cst @ 100°C) (ASTM D-445)	31.3	18.0	17.5
Viscosity (cst @ 40°C) (ASTM D-445)	254.1	138.2	136.5
Viscosity (cP @ 0°C) (ASTM D-2983)	-	1250	-
Viscosity (cP @ -18°C) (ASTM D-2983)	20,500	-	7,125
Viscosity (cP @ -20°C) (ASTM D-2983)	-	11,650	-
Viscosity (cP @ -26°C) (ASTM D-2983)	90,000	24,250	-
Viscosity (cP @ -40°C) (ASTM D-2983)	-	270,000	150,000
Viscosity Index (ASTM D-2270)	172	154	152

TYPICAL SPECIFICATIONS			
Flash Point (°C) (ASTM D-92)	207	235	207
Pour Point (°C) (ASTM D-97)	< -32	< -40	< -45
API Gravity @ 15°C (ASTM D-287)	22.3	23.0	24.3
Foam Test (ASTM D-892) Sequence 1:	Pass	Pass	Pass
Foam Test (ASTM D-892) Sequence 2:	Pass	Pass	Pass
Foam Test (ASTM D-892) Sequence 3:	Pass	Pass	Pass

*Please refer to the owner's manual and **Eaton**™ "Warranty Statement" for particular details.*